


Figure 10c.4 Determination of slope for impervious surface rule – diagram 2



$$\text{slope} = \frac{\text{distance between highest and lowest points of impervious surface at ground level (metres)}}{\text{highest contour} - \text{lowest contour (metres)}} = \frac{43}{9} \quad 1 \text{ in } 4.8$$

Scale = 1:50