


Figure 10c.4 Determination of slope for impervious surface rule – diagram 3



$$\text{slope} = \frac{\text{distance between highest and lowest points of impervious surface at ground level (metres)}}{\text{highest contour - lowest contour (metres)}} = \frac{52.5}{6.5} = 1 \text{ in } 8.1$$

Scale = 1:50